

How to Add Printer to Chromebook

Chromebook Printing is quite easy and advantageous. Read this guide which takes you through the Chromebook Printer Setup in wired and wireless printers.

Printing from a Chromebook has become easier over the years. Still, many of us have no idea of how to get started with the printing. You must add a printer to your Chromebook. The Chromebook's printing capabilities are managed by the Google Cloud Print services. The configuration sends documents to the printer wirelessly or connect a printer to Chromebook with wires. Cloud-ready and classic printers can be used with Chrome OS.

Add a Printer to Chromebook

If the Mac computer on which the printer is to be installed has a printer software, it should be removed from the computer.

- Step 1: Update the Chromebook to the most current version of Chrome OS.
- Step 2: Turn on the printer, install the cartridges, and load plain paper in it.
- Step 3: Connect the printer USB cable to the Chromebook.
- Step 4: Make sure you connect your Chromebook to the local network.
- Step 5: Connect your Windows or Mac computer with the same network.
- Step 6: Switch on the printer.
- Step 7: Download and install the Chrome browser on your computer.

- Step 8: Launch the Chrome browser.
- Step 9: Tap the three-dot icon in the upper right corner of the screen.
- Step 10: Choose Settings from the drop-down menu.
- Step 11: Navigate to the bottom and select Settings > Advanced.
- Step 12: Pick Google Cloud Print.
- Step 13: Select Manage Cloud Print devices.
- Step 14: Click Sign In link at the bottom of the page under My devices.
- Step 15: Type your Google credentials and continue.
- Step 16: View the list of available printers under My Devices.
- Step 17: Select the printer to be registered with Google Cloud Print. Hit Add printer.
- Step 18: The printer is now connected to the Chromebook

Add Cloud-Ready Printer to Chromebook

- Step 1: Power up the printer.
- Step 2: Visit CloudPrint in the Chrome browser.
- Step 3: Tap Add Cloud Ready Printer on the left side of the page.
- Step 4: View the list of cloud-ready printers.
- Step 5: Select your printer manufacturer.
- Step 6: You can see the list of supported models on the right of the screen.
- Step 7: Click the link in the center of the page and follow the steps.

- Step 8: Go back to CloudPrint.
- Step 9: Select Printers on the left menu page.
- Step 10: You'll find your printer enlisted.

For read more from this article, please click the below link

<https://installationsolutions.co/how-to-add-printer-to-chromebook>